

## Cruise Control.

1. Open Op-Com
2. Select year of car
3. Select model
4. Select engine code
5. Select programming
6. Select variant configuration
7. Select cruise control
8. Change from not present to present on the drop down menu
9. Click perform coding
10. Close program and enjoy your new cruise control

Depending on the year/model you may need the security code.